

Campable WiFi Connect

Contents of bag

- ✓ NetGear Hotspot
- ✓ USB cable
- ✓ Wall charger
- ✓ Jump Boost cable
- ✓ Cigarette Lighter Adapter

Connecting to hotspot

- 1 Make sure WiFi is enabled on your smartphone
- 2 Press power button on the hotspot to show the LCD screen
- 3 Search for WiFi networks on your smartphone and select the WiFi name displayed on the hotspot LCD screen
- 4 Enter your hotspot's WiFi password exactly as it appears on the LCD screen
- 5 You're ready to go!

Need help?

Visit www.campable.com/faq-wifi or email wifi@campable.com

Buying additional data

- 1 First, make sure you are connected to the hotspot. Then:
- 2 Go to connect.campable.com
- 3 Follow the instructions to buy a data pack

Charging the hotspot

- Your battery is partially charged when you first start your hotspot
- To recharge your battery, connect the micro USB cable to your hotspot
- Connect the other end of the cable to the USB charger, the USB port of a computer, or the car adaptor

Need help?

Visit www.campable.com/faq-wifi or email wifi@campable.com